



Cargo Bike User Guide

Before You Ride

- Adjust saddle height
- Check brakes
- Check battery level
- Secure your load
- Plan your route

Riding

- Allow extra distance for braking
- Take corners slowly and widely
- Be aware of the bike's increased length and weight
- Ride at a comfortable speed
- Hill starts can be tricky, make sure you have some momentum.

Loading

Maximum recommended load: 80kg

- Distribute weight evenly
- Place heavier items at the bottom
- Secure loose materials
- Avoid overloading
- No passengers

Locking

- Always use the supplied lock.
- Lock the frame to a fixed object.
- Remove battery if leaving for an extended period.
- Do not leave valuable materials unattended.

Problems?

If the bike is damaged, stolen, or develops a fault:

Call or text:
07576 333638

Email:
hub@canarts.org.uk